## **LAB NO: 8**

# **Configuring DHCP server on Cisco Router**

#### **Objective:**

To configure a Cisco router to act as a Dynamic Host Configuration Protocol (DHCP) server and dynamically assign IP addresses to clients in a local network.

#### **Apparatus Required:**

- Cisco Packet Tracer software
- PCs (or network devices) to act as DHCP clients
- Network cables for connecting devices
- A router (Cisco 1841)
- A switch (if multiple clients are used)

#### Theory:

DHCP (Dynamic Host Configuration Protocol) is a network management protocol used to automatically assign IP addresses, subnet masks, default gateways, and DNS server information to network devices. A router configured as a DHCP server can dynamically assign these details to clients in a specified IP range, reducing the need for manual IP configuration.

#### **Steps Involved in DHCP Configuration:**

The steps provided below can be followed to configure DHCP on the Cisco Router to assign a dynamic IP address to host systems deployed in the network:

#### **Step-1: Network Setup:**

Design the network by connecting the router to the switch and use an Automatic connecting cable to connect multiple PCs or devices to the switch as shown in Figure 1.

#### Step-2: Configuring the Router as a DHCP Server:

Access the Router's CLI (Command Line Interface)

Use the console connection to access the router's CLI.




Figure 1: DHCP Configuration




Figure 2: The Router's CLI

#### **Step-3:** Configuring Router with IPv4 Address and Subnet Mask.


### IP Addressing Table for Router:

| S.NO | Device  | Interface       | IPv4 Address | Subnet Mask   |
|------|---------|-----------------|--------------|---------------|
| 1.   | router0 | FastEthernet0/0 | 192.168.0.1  | 255.255.255.0 |
|      |         | FastEthernet0/1 | 192.168.1.1  | 255.255.255.0 |

- To assign an IP address in router0, click on router0.
- Then, go to config and then Interfaces, and make sure to turn on the ports.
- Then, configure the IP address in FastEthernet according to IP addressing Table.
- Fill IPv4 address and subnet mask.


**Step 4:** Configuring the PCs and changing the IP configuration.

- To assign an IP address in PC3, click on PC3.
- Then, go to desktop and IP configuration and there you will find IPv4 configuration.
- Change its state from static to DHCP.
- It will automatically fetch the data and configure itself.



**Step 5:** Repeat the same procedure with other PCs to configure them thoroughly.

**Step-6:** To check the connectivity between the host systems, the 'ping' command is used to exchange data packets. All the data packets are successfully transferred, which ensures that a communication channel is established.



Connectivity Testing