# **LAB NO: 6**

# Designing Computer Network using SWITCH and ROUTER on Cisco Router

# A. Designing Computer Network using ROUTER

#### **Objective:**

To design and configure a computer network using a Cisco router, allowing different devices in the network to communicate effectively through routing.

# **Required Equipment:**

- Cisco Packet Tracer software
- 1 Router (e.g., 1841)
- 2 PCs
- Cables (automatic connection type)

# Step 1: Set Up the Topology

#### 1. Drag and Drop Devices:


 Add one router and two PCs from the device list into the workspace in Cisco Packet Tracer.

#### 2. Connect the Devices:

 Use crossover cables to connect each PC directly to the router's FastEthernet ports.

#### Example:

- o PC0 ↔ Router (FastEthernet 0/0)
- o PC1 ↔ Router (FastEthernet 0/1)



Step 2: Configure the IP Address on Each PC

# 1. PC0 Configuration:

o Click PC0 → Desktop → IP Configuration.

Set IP address: 192.130.50.1.

Set Subnet Mask: 255.255.255.0.


Set Default Gateway: 192.130.50.2

# 2. **PC1 Configuration**:


Set IP address: 192.130.40.1.

Set Subnet Mask: 255.255.255.0.

Set Default Gateway: 192.130.40.2



- Set Router's IP for FastEthernet 0/0: 192.130.50.2
- Set Router's IP for FastEthernet 0/1: 192.130.40.2



# **Step 3: Testing Connectivity**

# 1. Ping Test:

• From **PC0**, go to the command prompt and type:

ping 192.130.50.1

o From **PC1**, ping 192.130.40.1 to ensure communication between the two PCs.

### **B.** Designing Computer Network using SWITCH

C.

# **Objective:**

To design and configure a simple network in Cisco Packet Tracer using switches to connect multiple PCs.

# **Required Equipment:**

- Cisco Packet Tracer software
- 1 Cisco Switch (Switch-PT)
- 3PCs
- Cables (Copper Straight-through Ethernet cables)

# **Step-by-Step Procedure:**

# Step 1: Set Up the Topology

#### 1. Add Devices:

 Drag and drop one switch and three PCs from the device list into the workspace in Cisco Packet Tracer.

#### 2. Connect Devices:

Use straight-through cables to connect each PC to the switch.

#### Example:

- o PC0 ↔ Switch (FastEthernet 0/1)
- o PC1 ↔ Switch (FastEthernet 0/2)
- Laptop0 ↔ Switch (FastEthernet 0/3)

#### **Step 2: Configure IP Addresses on Each PC**

#### 1. PC0 Configuration:

- Click PC0 → Desktop → IP Configuration.
- o Set the IP Address: 192.30.20.1

Set the Subnet Mask: 255.255.255.0

Leave the Default Gateway field blank, as there is no router in this setup.

#### 2. **PC1 Configuration**:

Set the IP Address: 192.30.20.2

Set the Subnet Mask: 255.255.255.0

### 3. PC2 Configuration:

Set the IP Address: 192.30.20.3

Set the Subnet Mask: 255.255.255.0

### **Step 4: Test the Connectivity**

#### 1. Ping Between PCs:

From **PC0**, go to the command prompt and ping **PC1** by typing:
 ping 192.30.20.1

Test connectivity by pinging from PC0 to other PCs (PC2, PC3) as well.

# 2. Verify:

• If the pings are successful, it indicates that the PCs are correctly communicating with each other through the switch.

```
Physical Config Desktop Programming Attributes

Command Prompt

Cisco Packet Tracer PC Command Line 1.0
C:\>ping 192.30.20.2

Pinging 192.30.20.2 with 32 bytes of data:

Reply from 192.30.20.2: bytes=32 time=lms TTL=128
Reply from 192.30.20.2: bytes=32 time<1ms TTL=128
Ping statistics for 192.30.20.2:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\>
```